MetroCount[®]

Type of Counter	Pneumatic tubes	Piezoelectric strips	Inductive loops	Magnetometers
Classification Type	Based on vehicle axles	Based on vehicle axles	Based on the length of vehicles	Based on the length of vehicles
Classification Categories	15+	15+	4-5	4-5
Bicycle Classification	\bigcirc	\bigcirc	\bigotimes	\bigotimes
Ease of installation	$\bigstar \bigstar \bigstar \bigstar \bigstar$	$\bigstar \bigstar \bigstar$	$\bigstar \bigstar \bigstar \bigstar$	$\bigstar \bigstar \bigstar \bigstar \bigstar \bigstar$
Installation Type	Temporary Semi-permanent	Permanent	Permanent	Permanent
Records volume, speed, class, direction, gap & headway	\bigcirc	\bigcirc	*Single loops provide volume, gap & headway only.	\bigotimes
Watch installation preview video	How to Install Tube Traffic Counter	Piezo Traffic Counter Installation Timelapse	How to Install Inductive Loops Road Traffic Data	How to install RoadPod VM
Compatible Products	<u>RoadPod® VT</u> <u>RoadPod® VT4</u> <u>RoadPod® PhaseT</u> <u>RidePod® BT bike counter</u>	<u>RoadPod[®] VP RidePod®</u> <u>BP bike counter</u>	<u>RoadPod[®] VL 5805</u> (single loop) <u>RoadPod[®] VL 5810</u> (dual loop)	<u>RoadPod® VM</u>

www.metrocount.com